



SS9001

Specifications

SOLENIOD OE

Number	Details
UD13803SS	AS-PL
UD14438SS(ZM)	AS-PL
UD16150SS	AS-PL
136632	CARGO
CQ2030063	CQ
227108	ERA
227743	ERA
E90Z-11390-A	FORD
E90Z-11390-B	FORD
F02Z-11390-A	FORD
F3VY-11390-A	FORD
F3VY-11390-B	FORD
F4DZ-11390-A	FORD

SW2188	FORD
SW2207	FORD
SW2245	FORD
SW2502	FORD
SW2502A	FORD
SW5038	FORD
SSF6632	KRAUF
940113050263	MAGNETI MARELLI
940113050403	MAGNETI MARELLI
AME0263	MAGNETI MARELLI
AME0403	MAGNETI MARELLI
1016490	POWERMAX
81016490	POWERMAX
66-205	WAI/TRANSP0
66-205-B24	WAI/TRANSP0
60-02-5510	WILSON
SND12250	WOODAUTO
ZM1760	ZM
ZM760	ZM

FOR STARTER

Number	Details
E90F11000AA	FORD-01
E90F11000BA	FORD-01
E90Y11002A	FORD-01
E90Y11002B	FORD-01
E9SF11000AA	FORD-01
E9SF11000BA	FORD-01
E9SZ11002A	FORD-01
E9SZ11002B	FORD-01
E9Y111002A	FORD-01
E9Y111002B	FORD-01
F02F11000AA	FORD-01

F02U11000AA	FORD-01
F02Z11002A	FORD-01
F07U11000AA	FORD-01
F07U11000BA	FORD-01
F0CF11000AA	FORD-01
F0CF11000BA	FORD-01
F0CU11000AA	FORD-01
F0CU11000AB	FORD-01
F0CU11000BA	FORD-01
F0CU11001AA	FORD-01
F0CU11001AB	FORD-01
F0CU11001BA	FORD-01
F0FZ11002A	FORD-01
F0FZ11002B	FORD-01
F0OU11000AA	FORD-01
F0OY11002A	FORD-01
F0TZ11002A	FORD-01
F0TZ11002B	FORD-01
F13U11000AA	FORD-01
F13Z11002A	FORD-01
F17U11000AB	FORD-01
F1TZ11002A	FORD-01
F1VU11000AA	FORD-01
F1VY11002A	FORD-01
F23U11000AA	FORD-01
F23U11000BC	FORD-01
F23Z11002A	FORD-01
F23Z11002B	FORD-01
F2DU11000AA	FORD-01
F2DU11000BA	FORD-01
F2DZ11002A	FORD-01
F2HT11000AA	FORD-01
F2HT11000BA	FORD-01
F2HZ11002A	FORD-01

F2HZ11002B	FORD-01
F2TU11000AA	FORD-01
F2TU11000BA	FORD-01
F2TU11000CA	FORD-01
F2TZ11000AC	FORD-01
F2TZ11002A	FORD-01
F2TZ11002B	FORD-01
F2TZ11002C	FORD-01
F2VU11000AD	FORD-01
F2VY11000AC	FORD-01
F2VY11000AD	FORD-01
F2VY11002A	FORD-01
F3DU11000AA	FORD-01
F3DU11000BA	FORD-01
F3DZ11002A	FORD-01
F3DZ11002B	FORD-01
F3LU11000AA	FORD-01
F3LY11002A	FORD-01
F4CU11000AA	FORD-01
F4CU11000BA	FORD-01
F4FU11000AA	FORD-01
F4LU11000AA	FORD-01
F67U11000AA	FORD-01
F67Z11002AA	FORD-01
F6DU11000AA	FORD-01
F6DZ11002A	FORD-01
F90F11000AA	FORD-01
F90F11000BA	FORD-01
E9SF-11000-AA	FORD-01
E9SF-11000-BA	FORD-01
E9SZ-11002-A	FORD-01
E9SZ-11002-B	FORD-01
E9Y1-11002-A	FORD-01

E9Y1-11002-B	FORD-01
F02F-11000-AA	FORD-01
F02U-11000-AA	FORD-01
F02Z-11002-A	FORD-01
F07U-11000-AA	FORD-01
F07U-11000-BA	FORD-01
F0CF-11000-AA	FORD-01
F0CF-11000-BA	FORD-01
F0CU-11000-AA	FORD-01
F0CU-11000-AB	FORD-01
F0CU-11000-BA	FORD-01
F0CU-11001-AA	FORD-01
F0CU-11001-AB	FORD-01
F0CU-11001-BA	FORD-01
F0FZ-11002-A	FORD-01
F0FZ-11002-B	FORD-01
F0OU-11000-AA	FORD-01
F0OY-11002-A	FORD-01
F0TZ-11002-A	FORD-01
F0TZ-11002-B	FORD-01
F13U-11000-AA	FORD-01
F13Z-11002-A	FORD-02
F17U-11000-AB	FORD-02
F1TZ-11002-A	FORD-02
F1VU-11000-AA	FORD-02
F1VY-11002-A	FORD-02
F23U-11000-AA	FORD-02
F23U-11000-BC	FORD-02
F23Z-11002-A	FORD-02
F23Z-11002-B	FORD-02
F2DU-11000-AA	FORD-02
F2DU-11000-BA	FORD-02
F2DZ-11002-A	FORD-02
F2HT-11000-AA	FORD-02

F2HT-11000-BA	FORD-02
F2HZ-11002-A	FORD-02
F2HZ-11002-B	FORD-02
F2TU-11000-AA	FORD-02
F2TU-11000-BA	FORD-02
F2TU-11000-CA	FORD-02
F2TZ-11002-A	FORD-02
F2TZ-11002-B	FORD-02
F2TZ-11002-C	FORD-02
F2VY-11000-AC	FORD-02
F2VY-11000-AD	FORD-02
F2VY-11002-A	FORD-02
F3DU-11000-AA	FORD-02
F3DU-11000-BA	FORD-02
F3DZ-11002-A	FORD-02
F3DZ-11002-B	FORD-02
F3LU-11000-AA	FORD-02
F3LY-11002-A	FORD-02
F4CU-11000-AA	FORD-02
F4CU-11000-BA	FORD-02
F4FU-11000-AA	FORD-02
F4LU-11000-AA	FORD-02
F67U-11000-AA	FORD-02
F67Z-11002-AA	FORD-02
F6DU-11000-AA	FORD-02
F6DZ-11002-A	FORD-02
F90F-11000-AA	FORD-02